

Xtellio Help Center Documentation

Set up instructions


- 1. Navigate to your Fill-Rite account
 - a. Go to the My Assets > Hardware section
 - b. Click the Tank Monitor tab and click Add tank monitor




2. Select the **Xtellio** Tank Monitor option




3. Enter your Xtellio Account information




- 4. Select a Fill-Rite Site to add your Xtellio Tank Monitor
 - a. Note: This step will be skipped if adding the device on a Site Detail page.
 - b. **Note:** If you are sharing this device with a customer, choose the **Share** with customer at the bottom.




5. Activate your Subscription. You can choose 1-, 3-, 6-, or 12-month subscription lengths at the price of \$5/month.




6. Click **Configure** to select your Tank Monitor and connect it to a Tank. If clicking **Configure** from the Hardware page, you will be taken to the **Site Detail** page to configure your Tank Monitor.




7. Click the + icon next to the tank monitor to select the tank and finish the setup




8. Select the Xtellio Tank Monitor you would like to configure



9. Select the Fill-Rite tank you would like to connect




10. Confirm your selections




Other Functionality

Share your Xtellio Tank Monitor

From the Hardware page click the Quick Menu settings cog, then select Share



Or start sharing when first adding the tank monitor



Then select the **Customer** and **Site** to share the device with

